
Operation no. of operation texts and work units or standard texts and flat rates $% \left(1\right) =\left(1\right) \left(1\right)$

Combustion chambers


The combustion chambers of the cylinder heads of engines 103.94 and 103.98 differ and must not be interchanged. In addition, the cylinder heads of the engines with open combustion chamber (2nd version) differ to the cylinder heads used previously with squash areas (1st version).

Use cylinder head 1st version (squash areas) only together with the relevant pistons (see replacement parts).



P01-6041-13

Use cylinder head 2nd version with open combustion chamber (arrow) only together with the relevant pistons.



P01-6042-13

1