



Special tools



- This procedure requires vehicle to be driven onto a drive-on lift.
- Position special tool (090) 129 589 06 21 00 under ball joint (arrow).



- By lifting/lowering control arm (4) using special tool (loading/unloading wheel), any play (a) present in the ball joint can be observed by an assistant.
- If play is found in the control arm, ball joint or control arm (on versions with integral ball joints) must be replaced on separate order.

